

Ground Ripper



P

Pieces Needed:



Will be broken to 4 sections:



Section 1:





Section 2:





Sections 3:






Missile will have to be cut flush.





Section 4:









Assembly:





